

WULF MODS

UNI 3.0



Quick Start Guide

Compiled by *Waterbeds'n'Stuff*



Wulf Mods UNI 3.0

INCLUDES

- Wulf UNI 3.0 Battery
- 510 Magnetic Adapter
- Type-C USB Cable
- User Manual



UNI 3.0 OVERVIEW



CHARGING THE **UNI 3.0**

FIRST CHARGE

- ▶ WHEN YOU FIRST RECEIVE THE DEVICE, CONNECT THE TYPE-C CHARGER TO THE CHARGING PORT.
- ▶ CHARGING TIME FOR THE DEVICE IS 1 HOUR.
- ▶ DO NOT CHARGE IT FOR MORE THAN 1 HOUR. CHARGING THE BATTERY FOR MORE THAN 1 HOUR COULD RUIN THE BATTERY OR WEAR DOWN THE LIFESPAN.

CHARGING INDICATOR

- ▶ ONCE THE CHARGER IS PLUGGED IN, THE BATTERY INDICATOR ON THE SCREEN WILL DISPLAY PERCENTAGE. WHEN IT IS AT 100%, THE BATTERY INDICATOR WILL TURN OFF.




ADJUSTING THE **UNI 3.0**

ADJUSTING CARTRIDGE HEIGHT



- ▶ THE UNI 3.0 IS COMPATIBLE WITH CARTRIDGE LENGTHS 42MM AND OVER.
- ▶ SIMPLY PRESS THE HEIGHT SWITCH UP OR DOWN TO ADJUST THE HEIGHT OF YOUR ATOMIZER.

ADJUSTING CARTRIDGE WIDTH



- ▶ THE UNI 3.0 IS COMPATIBLE WITH UP TO 2 GRAM CARTRIDGES. IT HAS A DIAMETER RANGE OF 11MM-16MM.

- ▶ THE DIAL ADJUSTS THE DIAMETER OF THE VALVE. MAKE SURE THE CARTRIDGE IS PERFECTLY SECURED.



LOADING THE **UNI 3.0**

- ▶ REMOVE THE MOUTHPIECE FROM THE CARTRIDGE.
- ▶ NOW LOAD THE DESIRED AMOUNT OF OIL INTO THE CARTRIDGE.
- ▶ TWIST MOUTHPIECE BACK ONTO THE CARTRIDGE.
- ▶ TWIST 510 ADAPTER ONTO THE CARTRIDGE.
- ▶ PLACE CARTRIDGE INTO THE CHAMBER AND ADJUST HEIGHT/WIDTH UNTIL PERFECTLY SECURED.
- ▶ ENJOY!

***CARTRIDGE NOT INCLUDED**



USING THE UNI 3.0

GETTING STARTED

TURN ON/TURN OFF

- ▶ PRESS POWER BUTTON RAPIDLY 5X TO TURN ON/OFF.

5x



CHANGE UI MODES

- ▶ PRESS THE POWER BUTTON 3X TO ENTER THE UI SELECT INTERFACE. CLICK THE -/+ BUTTON TO SELECT AND THEN PRESS THE POWER BUTTON 1X TO CONFIRM SELECTION.

3x



ADJUST VOLTAGE

- ▶ PRESS THE - OR + BUTTON TO GO DOWN OR UP 0.1V INCREMENTS. ADJUST UNTIL YOU HAVE REACHED DESIRED VOLTAGE.

PREHEAT MODE

- ▶ PRESS THE POWER BUTTON 2X TO PREHEAT DEVICE AT 1.8V FOR 10 SECONDS. TO CANCEL PREHEAT, PRESS THE POWER BUTTON AGAIN 2X.

RESET PUFF COUNTER

- ▶ PRESS THE POWER BUTTON AND THE - BUTTON AT THE SAME TIME TO RESET PUFF COUNTER.

KEY FEATURES:



ADJUST CART UP TO 2G



MAGNETIC 510 THREAD ADAPTER



1.8V 10 SEC PREHEAT



1.8V-4.2V ADJUSTABLE VOLTAGE



650MAH BATTERY



TROUBLESHOOTING THE **UNI 3.0**



▶ **SELECT UI MODE**



▶ **PREHEATING 10 SECONDS**



▶ **SAFETY CUT OFF IF POWER IS PRESSED FOR OVER 15 SECONDS**



▶ **RESET PUFF COUNTER**



▶ **PLEASE CHARGE THE DEVICE**



▶ **SHORT CIRCUIT**



▶ **BATTERY CHARGING**